

PUR35

Compact, mobile, multi-use fume extraction unit

PUREX
CLEAN AIR FOR EVERYONE



Description & features

- High performing cost effective machine
- Highest grade HEPA and carbon technology
- Filter blocked alarm to warn the operator
- Adjustable airflow

Filters



Main Filter Code

113860

Description

Chemical



Main Filter Code

113841

Description

HEPA



Pre-Filter Code

200500

Description

F8 Pleat Pack

Specification

Voltage	90v - 254v
Volume Part Number	0AL4170
Wattage	1.1kW
Frequency	50Hz / 60Hz
Cabinet Height	630mm
Cabinet Width	370mm
Cabinet Depth	520mm
Cabinet Weight	37kg
Airflow	400m3/h
Sound Level	<60dBa

Machine supplied with

- 2 x Main Filter • 1 x Pre-filter • 1 x Connection Kit • 1 x Power Cable • 1 x Manual

Find out more: W purex.co.uk | [T +44 \(0\)1405 746030](tel:+44(0)1405746030) | [E purex@purex.co.uk](mailto:purex@purex.co.uk)

Registered Office: Purex International LTD, Unit A, Saltgrounds Road, Brough, HU15 1EG, UK

Registered No. 5136616 England | VAT No. GB842 5025 49 | WEEE Producer Registration Number: WEE/CE0067TX

*Goods are subject to change | *Illustrations are 3D created visual representations

PUR35

Compact, mobile, multi-use fume extraction unit

Options

Connection kit

100105

Hose End Diameter	Hose Length	Purex Inlet Diameter
100mm	2m	100mm

Connect to 100mm diameter pipe/port

2.0m

100107

Hose End Diameter	Hose Length	Purex Inlet Diameter
100mm	3m	100mm

Connect to 100mm diameter pipe/port

3.0m

100191

Hose End Diameter	Hose Length	Purex Inlet Diameter
50mm	2m	100mm

Connect to 50mm diameter pipe/port or Purex valve

1.5m 0.5m

100193

Hose End Diameter	Hose Length	Purex Inlet Diameter
50mm	3m	100mm

Connect to 50mm diameter pipe/port or Purex valve

3m

120270

Hose End Diameter	Hose Length	Purex Inlet Diameter
100mm	1.5m	100mm

Connect to 100mm diameter pipe/port

1.5m

120292

Hose End Diameter	Hose Length	Purex Inlet Diameter
80mm	1.3m	100mm

Connect to 80mm diameter pipe/port

1.3m

PUR35

Interfacing

Interfacing can remotely start the Purex machine when the connected machine starts.

Interfacing can also warn the connected machine when the Purex machine is in alarm.

Your Machine

10011010



10011010

Extractor

Take a look through our [Interfacing Guide](#) to see our extensive range of options